### **BDF1630X**

## 16 Place Setting Freestanding Dishwasher Stainless with **Everclean Filter**





**WELS Water** 





**Place Setting** 

Rating

**Energy Rating** 

**Noise Level** 

43 dBA

16

**Programs** 

10 •Eco (45°C)

•Auto (40°C - 65°C) Baby Protect (70°C)

Number of Programs

AquaFlex •Intensive (70°C)

•Quick & Shine (60°C) PreWash

•Mini 30' (35°C)

InnerClean

•Glass Care (40°C)

**Auxiliary Functions:** 

Fast+, EverClean Filter,

SteamGloss, AquaIntense

3 Height Loaded Adjustable

3 (Upper), 8 (Lower) Basket

Tray Wash Holder, Glass Holder

Operating Noise: **Main Features** 

**Capacity** 

Design

Colour:

**Performance** 

**Energy Rating:** 

WELS Water Rating:

Water Consumption:

**Energy Consumption:** 

Number of Place Settings:

**Touch Button Control** Program Controls: White Digital LED Screen Type:

16

Stainless

5 Stars

13 litres

4 Stars

43 dBa

263 kWh

Flexible Half Load Opton: Yes Time Delay Function: Yes

Tablet Detergent Function: Automatic Electronic Rinse Aid Indicator: Yes

Number of Spray Levels: 3 + AquaIntense Spray Arm

Prosmart Inverter™ Motor Type:

Closed Fan Drying System: Dirt Sensor: Yes

Filter Type: Everclean™ Filter

Safety:

Water Safety System: Overflow Safety & Watersafe+

Water Leakage Indicator: Yes Key Lock: Yes

7631969077 Sku: 8690842194832 Ean Code:

Manufacturers Warranty: 2 Years + 3 Years by Registration

10 Years on Inverter Motor

Launch Date: March 2019

# Flexibility:

Height Adjustable Upper Rack:

Height Adjustable Mug Shelf: Yes x4

Folding Tines:

Largest dish in upper basket:

Largest dish in lower basket:

**Cutlery Basket:** 

Slide Out 3rd Cutler y Tray:

Accessories:

**Dimensions & Weights** 

Unpackaged Height: Height (max - feet adjustment):

Unpackaged Width:

Unpackaged Depth: Depth with Door Opened: Unpackaged Weight:

Packaged Width: Packaged Depth:

Packaged Height:

20 cm

28 cm

Sliding

850 mm 865 mm

Full Size, Flexible

598 mm 600 mm

1150 mm 50.6 kg

897 mm

657 mm 674 mm

Packaged Weight: 56.2 kg



#### ©Beko 2021

### beko.com.au / beko.co.nz



**Everclean™ Filter** - If you're tired of checking your dishwasher filter, or not doing so but then worrying about where all the dirt goes, meet the EverClean™ filter. It's a sprinkler system that rinses the filter with pressurised water to remove leftover food and odour after each wash. All so your dishes come out brilliantly clean week after week.



**Aquaintense**® - There's an easy way to wash those hard-to-clean dishes. Aquaintense® creates a powerful cleaning zone with intense water pressure, so even your filthiest pots and pans get expertly cleaned. No matter what you make, or how long it cooks, your dishes come out spotless.



**16 Place Setting** - Perfect for big, busy families. The flexibility of the top cutlery tray, unique shape of the top basket and foldable tines throughout the dishwasher provides it's large capacity and allows you to fit more in... so you can fit it all in, in one wash.

**Dimensions** 



